



41385 - Vehicle Wiring Installation Instructions

Buick Lacrosse 2005 – 2009

1. Open trunk and remove threshold panel. Partially remove the felt trunk liner behind the taillights. Remove both taillight housing assemblies by removing the two wing nuts on each taillight assembly and carefully pulling the vehicle taillight housing directly rearward away from the vehicle, being careful not to break the alignment tabs.
2. On the Driver's side, disconnect the vehicle wiring harness from the taillight socket. Plug the Hopkins® T-Connector end with the yellow wire in-between the mating plugs on the driver's side taillight socket and vehicle wiring harness.
3. On the driver's side, route the T-Connector end with green wire down through the opening below the taillight assembly and behind the bumper to the passenger side. Route T-Connector end with the green wire up through the opening below the taillight assembly and attach in-between the mating plugs on the passenger side taillight assembly.
4. Route the 4-way flat harness below the taillight assembly to either side of the receiver hitch and secure it with ny-ties. (provided)
5. Locate a suitable grounding point near the 4-way connector to attach to vehicle's frame. Clean dirt, paint and rust proofing from area. Drill a 3/32" hole and secure white wire with ring terminal using self tapping screw (provided). Verify what is behind any surface prior to drilling to avoid damage to the vehicle. Do not drill into any exposed surfaces.
6. Reinstall the taillights, felt trunk liner, threshold panel and any other items removed during installation. Being careful to avoid any areas that could cut or pinch the wires.
7. Attach the 4-way flat dust cover (provided) to the 4-way flat connector.
8. Apply a small amount of grease (provided) to the 4-way flat terminals to prevent corrosion.
9. Plug completed wire harness into the trailer 4-way flat connector.
10. Test all functions with the engine running to ensure proper operation.

TIPS:

Grease applied to the wiring terminals on a regular basis will help prevent corrosion.

Always unplug boat trailer connector before backing trailer into the water.

Need Help? (English Only)
1-800-835-0129
techsupport@hopkinsmfg.com
www.hopkinstowingsolutions.com