

# CLASS 4 TRAILER HITCH

## R3-0860

Chevy Silverado 1500/ GMC Sierra 1500


### TOOLS REQUIRED:

DRILLS: NONE

WRENCHES: Ratchet, Torque Wrench,  
Socket Extension, 7/8", 21mm, 22mm

**HITCH RATING: 6,000 LBS WEIGHT CARRYING, 600 LBS TONGUE WEIGHT / 10,000 LBS WEIGHT DISTRIBUTING, 1,000 LBS TONGUE WEIGHT.**  
**WARNING: CONSULT VEHICLE OWNERS MANUAL FOR TOWING RECOMMENDATIONS. DO NOT EXCEED VEHICLE'S RECOMMENDED TOWING CAPACITY. THIS PRODUCT IS DESIGNED FOR TRAILER TOWING ONLY AND SHOULD NOT BE USED FOR ANY OTHER PURPOSE.**

**NOTE: INSTALL PARTS LOOSELY UNTIL ALL ATTACHMENTS HAVE BEEN MADE TO VEHICLE**



**Note:** Factory installed steel step bumper and brackets are required for use with this hitch application.

1. Remove the existing M14 hex bolts from the end of each frame rail and return to vehicle owner.
2. Raise the hitch into position, locating the rear most slots in the hitch under the weld nuts in the frame rails where the bolts in step 1 were removed.
3. Install new M14-2.00 x 45mm hex bolts, 1/2" flat washers and 14mm lock washers into weld nuts in the end of each frame rail. Install the remaining (2) M14-2.00 x 45mm hex bolts, 1/2" flat washers and 14mm lock washers into the weld nuts in the step bumper through the hanger on the hitch box.
4. Assemble the (4) 1/2-13 carriage bolts and block plates and insert the bolts from the top of the frame rails down into the (4) forward attachment slots in the hitch. Secure with the (4) 1/2-13 hex nuts and conical washers provided.
5. Tighten all 14mm fasteners to 115 LB-FT. Tighten all 1/2" fasteners to 60 LB-FT.

**Thank you for purchasing a Rigid Hitch**

|                          |                                   |                                  |
|--------------------------|-----------------------------------|----------------------------------|
| <b>Hardware Package:</b> | (4) M14-2.00 x 45mm hex bolts     | (4) 1/4 x 1-1/2 x 2 block plates |
|                          | (4) 14mm lock washers             | (4) 1/2 conical washers          |
|                          | (4) 1/2 flat washers              | (4) 1/2-13 heavy hex nuts        |
|                          | (4) 1/2-13 x 1-3/4 carriage bolts |                                  |

**GIVE THIS INSTRUCTION SHEET TO VEHICLE OWNER**

| <b>BOLT TIGHTENING TORQUE (LB-FT)</b> |               |                  |               |
|---------------------------------------|---------------|------------------|---------------|
| <b>BOLT SIZE</b>                      | <b>TORQUE</b> | <b>BOLT SIZE</b> | <b>TORQUE</b> |
| 3/8"                                  | 25 LB FT      | 8MM              | 20 LB FT      |
| 7/16"                                 | 50 LB FT      | 10MM             | 38 LB FT      |
| 1/2"                                  | 60 LB FT      | 12MM             | 68 LB FT      |
| 3/4"                                  | 120 LB FT     | 14MM             | 115 LB FT     |

**THIS PRODUCT COMPLIES WITH SAFETY SPECIFICATIONS AND REQUIREMENTS FOR SAE AND VESC REGULATION V-5 FOR CONNECTING DEVICES AND TOWING SYSTEMS. DO NOT MODIFY THIS PRODUCT. INSTALL ONLY ON SPECIFIED VEHICLES IN GOOD CONDITION.**

**RIGID**<sup>®</sup>  
**HITCH INCORPORATED**  
3301 WEST BURNSVILLE PARKWAY  
BURNSVILLE, MN 55337

REV.  
8/15